



Amazon Fire TV Stick Remote Motherboard Replacement

In this guide we will disassemble the Amazon Fire TV Stick remote and remove the motherboard allowing another to be installed.

Written By: Andrew Busse



INTRODUCTION

This guide takes you step by step through the process required to replace the motherboard of the Amazon Fire TV Stick Remote. This process is not difficult if you stick to this guide.



TOOLS:


- [iFixit Opening Tools](#) (1)
 - [Precision Tweezers Set](#) (1)
 - [Triangle Head screwdriver](#) (1)
-

Step 1 — Remote Motherboard



- Use a plastic opening tool to open the battery cover. Apply a small amount of force into the crease.
- Remove batteries.

Step 2



- Use a plastic opening tool to pry off the top black ring.

Step 3




- Remove the 6mm triangle head screw on the front of the remote.

Step 4




- Use two plastic opening tools to pry along the seam of the remote and separate the face plate.

Step 5



- Lift the rubber pad from the motherboard.

Step 6



- Use the opening tool to lift the back of the motherboard. Slowly lift the motherboard while keeping the wires straight.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 08:24:16 PM.